

SECTION 7: TROUBLESHOOTING

7.1 GENERAL INFORMATION

The information contained in this section has been compiled from years' worth of information gathered from the field. It contains symptoms and usual causes for the most common types of problems that may occur. All available data concerning the trouble should be systematically analyzed before undertaking any repairs or component replacement.

A visual inspection is worth performing for almost all problems and may avoid unnecessary additional damage to the machine. The procedures which can be performed in the least amount of time and with the least amount of removal or disassembly of parts, should be performed first. Adherence to a routine maintenance regimen will minimize the occurrence of many common problems. Refer to **Section 6.3, Maintenance Schedule Table** for a typical maintenance regimen program.

Although Vanair® strives to anticipate situations that may occur during the operation life of the machine package, the **Troubleshooting Guide (Section 7.3)** may not cover all possible situations. Be aware that additional troubleshooting information may be found in other sources such as the Engine Operator's Manual. Should the situation remain unresolved after exhausting available sources, contact the Vanair® Service Department at:

Phone: 800-526-8817 (toll free)

Phone: 219-879-5100, ext. 400

Fax: 219-879-5335

www.vanair.com

NOTE

When contacting the Vanair Service Department, please have machine serial number on hand to quickly expedite service. See *Figure 7-1* for machine serial plate location.



WARNING

DO NOT operate any of the Air N Arc 200 Series All-In-One Power System's functions if there is a known unsafe condition. Disable the equipment by disconnecting it from its power source. Install a lock-out tag to identify the equipment as inoperable to other personnel to prevent accidental application.



WARNING

Before starting, performing maintenance, or replacing parts, relieve the entire system pressure by opening the air tank drain valve, which will vent all pressure to the atmosphere.




Figure 7-1: Machine Serial Plate Location

7.2 A NOTE ON CONDENSATION DUE TO COMPRESSION

Liquid water occurs naturally in air lines as a result of compression. Moisture vapor in ambient air is concentrated when pressurized, and condenses when cooled in downstream air piping.

Compressed air dryers reduce water vapor concentration and prevent liquid water formation in compressed air lines. Dryers are necessary companion to air filters, aftercoolers, and automatic tank drains for improving the productivity of compressed air systems.

Water and water vapor removal increases the efficiency of air operated equipment, reduces contamination and rusting, increases service life of pneumatic equipment and tools, and prevents air line freeze ups. For assistance in dealing with water and water vapor removal, consult Vanair.®

| 7.3 TROUBLESHOOTING GUIDE | | |
|---|-----------------------------|---|
| Fault/Malfunction | Possible Cause | Corrective Action |
| ENGINE ^I | | |
| <i>For additional information concerning the engine, consult the Engine Operator's Manual</i> | | |
| Engine will not crank | Faulty battery connection. | Check for proper battery connections and battery charge. |
| | Battery out of power | Recharge or replace battery. |
| | Engine fuse blown or faulty | Check engine fuse: See Section 6.6, Servicing the System Fuses and Circuit Breakers , and/or consult the Engine Operator's Manual. |
| | Faulty starter connection | Check for proper electrical connections at starter. |
| Engine will crank, but not start | Low fuel and/or oil supply | Check fuel gauge. Check engine oil level; refer to Section 6.5.9.2, Checking the Engine Oil . Replenish as necessary. Consult the Engine Operator's Manual for additional information. |
| <i>Continued on next page</i> | | |

^I Do not attempt to service or replace major engine components, or any items that require special timing or adjustment procedures. Contact the Engine manufacturer.

| 7.3 TROUBLESHOOTING GUIDE | | |
|---|---|--|
| Fault/Malfunction | Possible Cause | Corrective Action |
| ENGINE (CONTINUED) | | |
| Engine will crank, but not start (continued) | Wrong fuel type fill | Use only clean, automotive grade gasoline—do not use E85, etc. Refer to Engine Operator’s Manual for information on engine fuel type to use. |
| | Pinched fuel line | Replace or reroute if necessary. |
| | Fuel filter(s) and/or fuel lines partly plugged | Replace fuel filter or lines. Refer to Section 6.5.9.4, Replacing the In-line Fuel Filters , and the Engine Operator’s Manual. |
| | Low battery voltage | Recharge or replace if necessary. |
| | | Loose connections; tighten connections. |
| | | Dirty connections; clean connections. |
| | Restricted engine air filter | Check that the air cleaner element and precleaner are clean and all components are properly secured (Section 6.5.9.1, Air Filter Maintenance). Clean or replace as necessary. |
| | Defective oil pressure switch | Check continuity, and replace Kohler® Oil Sentry Protection switch, if necessary (refer to Engine Operator’s Manual). |
| | | Remove wire—if it runs, the switch is faulty. |
| | Blown fuse | Check continuity, and replace if necessary. See Section 6.6, Servicing the System Fuses and Circuit Breakers , and/or consult the Engine Operator’s Manual. |
| | Poor ground connection | Check and clean/renew connection. |
| | Fouled spark plug | Check spark plug and replace if necessary. Refer to Engine Operator’s Manual. |
| Engine choke not operating properly | Check engine choke position. Refer to Engine Operator’s Manual. | |
| Broken or faulty wiring | Check harness connections and wiring condition. | |
| <i>Continued on next page</i> | | |

^I Do not attempt to service or replace major engine components, or any items that require special timing or adjustment procedures. Contact the Engine manufacturer.

| 7.3 TROUBLESHOOTING GUIDE | | |
|--|--|--|
| Fault/Malfunction | Possible Cause | Corrective Action |
| ENGINE (CONTINUED) | | |
| Improper Control Operation: Engine does not speed up | Throttle solenoid stuck | Check throttle solenoid. Replace if necessary. |
| | | Check throttle relay; replace if necessary. Refer to Section 6.6, Servicing the System Fuses and Circuit Breakers. |
| | Faulty throttle solenoid | Check throttle solenoid; replace if necessary. |
| | | Check throttle relay; replace if necessary. Refer to Section 6.6, Servicing the System Fuses and Circuit Breakers. |
| | Governor stuck | Free governor and lubricate if necessary. |
| | Fuel filter(s) and/or fuel lines partly plugged | Replace fuel filter or lines. Refer to Section 6.5.9.4, Replacing the In-line Fuel Filters, and the Engine Operator's Manual. |
| | Unloader valve(s) sticking or faulty | Refer to Section 6.5.3, Unloader Valve Maintenance, to clean or rebuild/replace. |
| | Blown system fuse | Check system fuse; replace if necessary. Refer to Section 6.6, Servicing the System Fuses and Circuit Breakers. |
| | Broken or faulty wiring | Check harness connections and wiring condition. |
| Improper Control Operation: Engine does not slow down | Leak in control line | Check for leaks; replace line if necessary. |
| | Pressure control out of adjustment or malfunctioning | Pressure settings may need to be reset. Consult Section 6.5.5, Adjusting the Cut-in / Cut-out Pressure. |
| | Unloader valve(s) sticking or faulty | Refer to Section 6.5.3, Unloader Valve Maintenance, to clean or rebuild/replace. |
| | Defective oil pressure switch | Check continuity, and replace Kohler® Oil Sentry Protection switch, if necessary (refer to Engine Operator's Manual). |
| | Throttle solenoid stuck | Check throttle solenoid. Replace if necessary. |
| <i>Continued on next page</i> | | |

[†] Do not attempt to service or replace major engine components, or any items that require special timing or adjustment procedures. Contact the Engine manufacturer.

| 7.3 TROUBLESHOOTING GUIDE | | |
|---|---|--|
| Fault/Malfunction | Possible Cause | Corrective Action |
| ENGINE (CONTINUED) | | |
| Improper Control Operation: Engine does not slow down (continued) | Throttle solenoid stuck (continued) | Check throttle relay; replace if necessary. Refer to Section 6.6, Servicing the System Fuses and Circuit Breakers. |
| | Broken or faulty wiring | Check harness connections and wiring condition. |
| Engine overheats | Located too close to obstruction | Move further from obstruction, or move obstructing obstacle(s). |
| | Restricted engine oil filter | Replace engine oil filter. Refer to Section 6.5.9.3, Replacing the Engine Oil. Also refer to the Engine Operator's Manual. |
| | Low oil level | Check engine oil level; refer to Section 6.5.9.2, Checking the Engine Oil. Replenish as necessary. Also refer to the Engine Operator's Manual. |
| | Restricted engine air filter | Check that the air cleaner element and precleaner are clean and all components are properly secured. Clean or replace as necessary. Refer to Engine Operator's Manual. |
| | Restricted cooling air in or out | Clean engine intake grill. refer to Section 6.5.9.5, Engine Cooler Maintenance. |
| | Engine oil cooler plugged | Clear debris/dirt from cooler core/flush shroud. Refer to Section 6.5.9.5, Engine Cooler Maintenance, and the Engine Operator's Manual. |
| Engine stops during operation | Low oil level | Check engine oil level; refer to Section 6.5.9.2, Checking the Engine Oil. Replenish as necessary. Consult the Engine Operator's Manual for additional information. |
| | Low fuel | Check fuel gauge. Fill as necessary. |
| | Fuel filter(s) and/or fuel lines partly plugged | Replace fuel filter or lines. Refer to Section 6.5.9.4, Replacing the In-line Fuel Filters, and the Engine Operator's Manual. |
| <i>Continued on next page</i> | | |

¹ Do not attempt to service or replace major engine components, or any items that require special timing or adjustment procedures. Contact the Engine manufacturer.

| 7.3 TROUBLESHOOTING GUIDE | | |
|---|---|--|
| Fault/Malfunction | Possible Cause | Corrective Action |
| ENGINE (CONTINUED) | | |
| Engine stops during operation (continued) | Wrong fuel type fill | Use only clean, automotive grade gasoline—do not use E85, etc. Refer to Engine Operator's Manual for information on engine fuel type to use. |
| | Restricted engine air filter | Replace. |
| | Restricted cooling air in or out | Clean engine intake grill. refer to Section 6.5.9.5, Engine Cooler Maintenance. |
| | Fouled spark plug | Check spark plug and replace if necessary. Refer to Engine Operator's Manual. |
| Gradual loss of engine power | Contaminated fuel | Drain and replace fuel supply. |
| | Wrong fuel type fill | Use only clean, automotive grade gasoline—do not use E85, etc. Refer to Engine Operator's Manual for information on engine fuel type to use. |
| | Engine air filter contaminated | Check air filter. Replace if necessary (refer to the Engine Operator's Manual). |
| | Fuel filter(s) and/or fuel lines partly plugged | Replace fuel filter or lines. Refer to Section 6.5.9.4, Replacing the In-line Fuel Filters, and the Engine Operator's Manual. |
| | Vapor lock | Machine overloading. Allow to cool. |
| | | Refer to " Engine overheats " section in this Troubleshooting Guide. |
| | Defective oil pressure switch | Check continuity, and replace Kohler® Oil Sentry Protection switch, if necessary (refer to Engine Operator's Manual). |
| | Fouled spark plug | Check spark plug and replace if necessary. See Engine Operator's Manual. |
| Engine choke not operating properly. | Check engine choke position. | |
| COMPRESSOR | | |
| Flywheel rotation slows down | Belt(s) slipping | Re-tension or replace belts. |
| Severe vibration | Bent crankshaft | Remove and replace. Contact Vanair for details. |
| <i>Continued on next page</i> | | |

[†] Do not attempt to service or replace major engine components, or any items that require special timing or adjustment procedures. Contact the Engine manufacturer.

| 7.3 TROUBLESHOOTING GUIDE | | | |
|--|---|---|---|
| Fault/Malfunction | Possible Cause | Corrective Action | |
| COMPRESSOR (CONTINUED) | | | |
| Abnormal noise | Loose valve assembly | Tighten valve bolt and lock nut. | |
| | Piston hits cylinder cover | Check piston & rod assembly for excessive wear. | |
| | Worn connecting rod bearing. | Replace bearing. | |
| Compressor overheats | Low compressor oil level | Check oil level and refill to proper level if necessary. Refer to Section 6.5.2, Compressor Oil Maintenance . Do not overfill. | |
| | Obstructed or restricted intake air flow | Check for obstructions (frame, body, etc.) to air filter vents. Replace air filter if necessary. Refer to Section 6.5.1, Compressor Air Filter . | |
| | Unloader valve(s) sticking or faulty | Refer to Section 6.5.3, Unloader Valve Maintenance , to clean or rebuild/replace. | |
| Compressor will not build up pressure | Worn valve plate | Repair or replace valve plate. | |
| | Valve springs have lost their temper | Replace valve springs. | |
| | Dirt on the valve plate | Remove and clean it. | |
| | Leaks from safety valve | Repair or replace safety valve. | |
| | Leaks from bolt holes | Tighten the nuts even with packing. | |
| | Uneven valve seat surface | Remove and lap the surface. | |
| | Excessive blow by on piston rings | Replace with new ones. | |
| | Bad packing (gasket too thick) | Replace packing (gasket). | |
| | Excessive air leaks | Eliminate air leaks. | |
| | Compressor system is not receiving enough operating power | If running more than one function simultaneously, turn off competing function. | |
| | Air demand too high | | Check for leaks and take corrective action. |
| | | | Check air tools for wear, damage, or malfunctions. Replace or repair. |
| Pressure control out of adjustment or malfunctioning | | Pressure settings may need to be reset. Consult Section 6.5.5, Adjusting the Cut-in / Cut-out Pressure . | |
| <i>Continued on next page</i> | | | |

| 7.3 TROUBLESHOOTING GUIDE | | |
|---|---|---|
| Fault/Malfunction | Possible Cause | Corrective Action |
| COMPRESSOR (CONTINUED) | | |
| Compressor will not build up pressure (continued) | Compressor capacity too low to accommodate demand | Substitute larger capacity compressor system. |
| | Obstructed or restricted intake air flow | Check for obstructions (frame, body, etc.) to air filter vents. Replace air filter if necessary. Refer to Section 6.5.1, Compressor Air Filter . |
| | Belt(s) slipping | Re-situate and adjust belt tension, or replace belt if necessary. Consult Section 6.5.7, Replacing and Re-tensioning the Compressor and/or Generator Drive Belts , and its sub-sections. |
| | Engine governor stuck | Free governor and lubricate if necessary. Consult the Engine Operator's Manual. |
| | Unloader valve(s) sticking or faulty | Refer to Section 6.5.3, Unloader Valve Maintenance , to clean or rebuild/replace. |
| | Pressure relief valve not operating properly | Replace if necessary. |
| | Leak in air system | Inspect air system for leaks. |
| | Faulty throttle solenoid | Check throttle solenoid; replace if necessary. Check throttle relay; replace if necessary. Refer to Section 6.6, Servicing the System Fuses and Circuit Breakers . |
| | Service valve is open | Close service valve. |
| | Pressure gauge is malfunctioning | Check pressure gauge function/control line routing: adjust, repair or replace as necessary. |
| | Pressure gauge is malfunctioning (continued) | Check for proper operation with an auxiliary air source. Replace if necessary. |
| | Discharge piping leaks | Tighten connections; replace faulty piping. |
| Slipping of belts | Working pressure too high | Lower working pressure. |
| | Improper belt tension. | Adjust belt tension. Consult Section 6.5.7, Replacing and Re-tensioning the Compressor and/or Generator Drive Belts , and its sub-sections. |
| <i>Continued on next page</i> | | |

| 7.3 TROUBLESHOOTING GUIDE | | |
|--|--|---|
| Fault/Malfunction | Possible Cause | Corrective Action |
| COMPRESSOR (CONTINUED) | | |
| Slipping of belts (continued) | Worn belt | Replace with new ones. |
| Inaccuracy of pressure gauge | Pressure gauge damaged | Replace. |
| Excessive moisture in the compressed air | Moisture accumulating in air tank | Drain water from air tank. Refer to Section 6.5.8, Draining the Air Tank . |
| Compressor system over-pressures and/or relief valve opens | Damaged/kinked control line | Check line for damage (wear, kinks, etc.). Re-route, re-tie or replace if necessary (refer to Appendix A, Hose Installation Guide for assistance in running or checking hose lines). |
| | Restriction in control line | Clean if soiled; if ice is present, clear and remove. |
| | Control line connections are not properly seated/poor connection quality | Check lines for proper seating/ensure line ends have been cut cleanly and are square (DO NOT use wire cutters: use a loom cutting tool or a clean, sharp razor blade). |
| | Pilot valve out of adjustment or malfunctioning | Pressure settings may need to be reset. Consult Section 6.5.5, Adjusting the Cut-in / Cut-out Pressure . |
| | Pressure gauge is malfunctioning | Check for proper operation with an auxiliary air source. Replace if necessary. |
| | | Check pressure gauge function/control line routing: adjust, repair or replace as necessary. |
| Defective safety valve | Replace safety valve. | |
| No service air output | If equipped, OSHA valve/velocity fuse, not functioning properly | Reset or replace OSHA valve. |
| | Belt(s) not adjusted properly, worn or slipping | Belt(s) out of position or malfunctioning. Consult Section 6.5.7, Replacing and Retensioning the Compressor and/or Generator Drive Belts , and its sub-sections. |
| System operating pressure below specified minimum | Air demand too high | Check air tools for wear, damage, or malfunctions. Replace or repair. |
| | Compressor capacity too low to accommodate demand | Substitute larger capacity compressor system. |
| <i>Continued on next page</i> | | |

| 7.3 TROUBLESHOOTING GUIDE | | |
|---|--|--|
| Fault/Malfunction | Possible Cause | Corrective Action |
| COMPRESSOR (CONTINUED) | | |
| System operating pressure below specified minimum (continued) | Pressure control out of adjustment or malfunctioning | Pressure settings may need to be reset. Consult Section 6.5.5, Adjusting the Cut-in / Cut-out Pressure . |
| System operating pressure below specified minimum (continued) | System leaks or is damaged | Inspect for leaks. Repair and/or replace damaged parts as necessary. Use Section 9, Illustrated Parts List to visually confirm/identify any part that needs to be replaced before ordering part. |
| | Pressure switch set too low/ malfunction | Adjust pressure switch setting. Refer to Section 6.5.5, Adjusting the Cut-in / Cut-out Pressure . Replace if switch continues to deviate from setting. |
| | Input rpm too low | Adjust to proper setting. |
| | Clogged compressor air filter | Check air filter. Replace if necessary; refer to Section 6.5.1, Compressor Air Filter . |
| | Incorrect engine speed | Reduce load. Refer to Section 6.5.6 . |
| | Pilot valve stuck open | Check valve; clean or replace if necessary. |
| Excess amount of oil in air discharge | Compressor oil level too high | The correct oil level is the half-way mark on the sight glass with the compressor shut down, and the machine on a level surface. Drain excess oil to correct level. Consult Section 6.5.2, Compressor Oil Maintenance . |
| Excessive oil consumption | Worn piston ring | Replace; consult Vanair® Service Department for piston ring and cylinder maintenance procedures. |
| | Worn piston | Replace; consult Vanair Service Department for piston ring and cylinder maintenance procedures. |
| | Worn cylinder | Replace; consult Vanair Service Department for piston ring and cylinder maintenance procedures. |
| DC GENERATOR | | |
| Welder and/or battery charger behave erratically | Connection cables or receptacles are soiled/contaminated | Check for twisted cables and/or soiled/contaminated or loose receptacle connections. |
| <i>Continued on next page</i> | | |

7.3 TROUBLESHOOTING GUIDE

| Fault/Malfunction | Possible Cause | Corrective Action |
|--|--|---|
| DC GENERATOR (CONTINUED) | | |
| Welder and/or battery charger behave erratically (continued) | Connection cables or receptacles are soiled/contaminated (continued) | Untwist and/or straighten out any suspected cable tensions. Carefully wipe off any contaminants to receptacle connectors before re-connecting. Replace any worn or damaged cables or receptacles. Contact Vanair® Mfg., Inc. Service Department if behavior persists. |
| | Welding function is not drawing enough operating power | If running more than one function simultaneously, turn off competing function. |
| No welder output | Fuse at welder field blown | Replace the welder field fuse. Refer to Section 6.6, Servicing the System Fuses and Circuit Breakers. |
| Display not working | Loose or faulty wiring | Check wiring: Loose—secure; faulty—replace. |
| Lights do not turn off | Battery charge low | Flip AC generator switch to bring engine to high rpm, and charge battery. |
| AC GENERATOR | | |
| No AC generator output | Serpentine belt out of position or malfunctioning | Re-situate and adjust belt tension, or replace belt if necessary. Consult Section 6.5.7, Replacing and Re-tensioning the Compressor and/or Generator Drive Belts , and its sub-sections. |
| | Loose or faulty wiring | Check wiring: Loose—secure ; faulty—replace. |
| | Circuit breaker blown | Replace the circuit breaker. Refer to Section 6.6, Servicing the System Fuses and Circuit Breakers. |
| Low AC voltage | Engine speed too low for demand | Adjust speed control. Consult Section 6.5.6, Adjusting the Engine Speed , and the Engine Operator's Manual. |
| High AC voltage | Engine speed too high for demand | Adjust speed control. Consult Section 6.5.6, Adjusting the Engine Speed , and the Engine Operator's Manual. |