

SECTION 6: TROUBLESHOOTING

6.1 GENERAL INFORMATION

The information contained in this section has been compiled from years' worth of information gathered from the field. It contains symptoms and usual causes for the most common types of problems that may occur. All available data concerning the trouble should be systematically analyzed before undertaking any repairs or component replacement.

A visual inspection is worth performing for almost all problems and may avoid unnecessary additional damage to the machine. The procedures which can be performed in the least amount of time and with the least amount of removal or disassembly of parts, should be performed first. Adherence to a routine maintenance regimen will minimize the occurrence of many common problems. Refer to **Table 5A: Maintenance Schedule**, for a typical maintenance regimen program.

Although Vanair® strives to anticipate situations that may occur during the operation life of the machine package, the **Troubleshooting Guide** may not cover all possible situations. Be aware that additional troubleshooting information may be found in other sources such as the Engine Operation Manual and the Generator Operation Manual. Should the situation remain unresolved after exhausting available sources, contact the Vanair Service Department at:

Phone: 800-526-8817 (toll free)

Phone: 219-879-5100, ext. 400

**Service (toll free): (844) VAN-SERV
(844) 826-7378**

Fax: 219-879-5335

NOTE

When contacting the Vanair Service Department, please have machine serial number on hand to quickly expedite service. See *Figure 6-1* for machine serial plate and serial number locations.

⚠ WARNING

DO NOT operate any of the PowerFlex™ AH's functions if there is a known unsafe condition. Disable the equipment by disconnecting it from its power source. Install a lock-out tag to identify the equipment as inoperable to other personnel to prevent accidental application.

⚠ WARNING

Before starting, performing maintenance, or replacing parts, relieve the entire system pressure by opening the air tank drain/vent valve, which will vent all pressure to the atmosphere.
Refer to *Figure 6-2*. Open fill cap **SLOWLY** (contents under pressure) to make sure all pressure has been relieved.




Figure 6-1: Machine Serial Plate / Serial Number Locations




Figure 6-2: Pressure Relief

6.2 TROUBLESHOOTING GUIDE		Use Section 7, Illustrated Parts List, to visually identify and confirm any part number that may need to be replaced.
Fault/Malfunction	Possible Cause	Corrective Action
ENGINE		
Engine will not crank	Machine hood shutdown safety switch prevents start-up of engine	Close hood panel or check if roof switch is faulty. See Section 1.10, Machine Canopy Access Safety Switches .
	Faulty battery connection.	Check for proper battery connections and battery charge.
	Engine fuse blown	Check engine fuse: See Section 5.4.5, Servicing the System Fuses and Circuit Breakers , and/or consult the Engine Operation Manual.
	Possible starter and/or solenoid problem	Replace if defective.
	Hood switch malfunction	Replace if defective
	Low or dead battery voltage	Recharge or replace battery.
	Poor grounding	Check and confirm ground connection.
	Possible seized engine	Consult the Vanair® Service Department.
Engine will not start	Low fuel and/or oil supply	Check fuel gauge. Check engine oil level. Replenish as necessary. Consult the Engine Operation Manual for additional information on engine maintenance.

Continued on next page

6.2 TROUBLESHOOTING GUIDE		Use Section 7, Illustrated Parts List, to visually identify and confirm any part number that may need to be replaced.	
Fault/Malfunction	Possible Cause	Corrective Action	
ENGINE (CONTINUED)			
Engine will not start (continued)	Pinched fuel line	Replace or reroute if necessary.	
	Plugged fuel filter(s)	Replace if necessary. Refer to the Engine Operation Manual.	
	Low battery voltage		Recharge or replace if necessary.
			Loose connections—tighten connections.
			Dirty connections—clean connections.
	Plugged engine air filter	Replace engine air filter. Refer to Engine Operation Manual.	
	Defective oil pressure switch	Check continuity, and replace if necessary.	
	Defective engine temperature switch	Check continuity, and replace if necessary.	
	Poor ground connection	Check and clean/renew connection.	
	Glow plugs not engaging	Check fuse, wiring, and Engine Operation Manual.	
	Fuel solenoid	Call the Vanair® Service Department.	
Air in the fuel line	Refer to Section 3.7, Venting the Fuel Line.		
Improper Control Operation: Engine does not speed up	Throttle solenoid cable improperly set	Call Vanair Service Department.	
	Operating pressure too high	Adjust to proper pressure setting. Refer to Section 5.4.2, Adjusting the Pressure Setting. Replace if switch continues to deviate from setting.	
	Fuel filter partly plugged	Replace fuel filter. Refer to the Engine Operation Manual.	
		Auxiliary fuel pump may be needed for remote fuel tank. Refer to Section 3, Installation.	
	Pressure switch faulty	Replace pressure switch.	
Defective Throttle Control Relay Solenoid not actuating	Inspect; replace if necessary.		
Improper Control Operation: Engine does not slow down	Leak in control line	Check for leaks; replace line if necessary.	
	Generator switch left on	Turn generator switch off.	

Continued on next page

6.2 TROUBLESHOOTING GUIDE		Use Section 7, Illustrated Parts List, to visually identify and confirm any part number that may need to be replaced.
Fault/Malfunction	Possible Cause	Corrective Action
ENGINE (CONTINUED)		
Improper Control Operation: Engine does not slow down (continued)	Pressure switch out of adjustment	Adjust to proper pressure setting. Refer to Section 5.4.2, Adjusting the Pressure Setting . Replace if switch continues to deviate from setting.
	Pressure switch faulty	Replace pressure switch.
	Throttle solenoid stuck	Free governor and lubricate if necessary. Refer to Engine Operation Manual.
Engine overheats	Low oil level	Check engine oil level. Consult the Engine Operation Manual for additional information on engine maintenance.
	Engine coolant level low	Check coolant level; add if necessary.
	Located too close to obstruction	Move further from obstruction.
	Engine oil filter plugged	Replace engine oil filter. Refer to Engine Operation Manual.
	Engine oil cooler plugged	Clear debris/dirt from cooler core.
	Restricted, or plugged, cooling air in or out	Clear debris/dirt from engine cooler.
	Faulty hydraulic fan pump / motor	Repair hydraulic fan pump / motor.
	Fault with engine cooling system	Consult Engine Operation Manual.
	Fan not operating	Check belt; check compressor oil level (ensure machine is parked on a level surface); check hydraulic motor/pump.
Engine stops during operation	Belt access panel switch faulty	Close access panel.
		Check switch.
	Low oil level	Check engine oil level. Consult the Engine Operation Manual for additional information on engine maintenance.
	Low Fuel	Check and refill fuel tank if necessary.
	High engine temperature	Let engine cool. Check for engine coolant level. Refer to <i>Engine Overheats</i> fault.
	Excessive hydraulic pressure overload	Check hydraulic pressure.
Plugged air filter	Check and replace air filter element if necessary.	
<i>Continued on next page</i>		

6.2 TROUBLESHOOTING GUIDE		Use Section 7, Illustrated Parts List, to visually identify and confirm any part number that may need to be replaced.
Fault/Malfunction	Possible Cause	Corrective Action
ENGINE (CONTINUED)		
Engine stops during operation (continued)	Engine shutdown switch activated	Confirm that access door is properly in place. Replace faulty engine shutdown switch; see Section 1.10, Machine Canopy Access Safety Switches .
Gradual loss of engine power	Contaminated fuel	Draw and replace fuel supply.
	Engine air filter contaminated	Check engine air filter. Replace if necessary (refer to the Engine Operation Manual).
	Fuel filter(s) contaminated	Check fuel filters. Refer to the Engine Operation Manual.
	Low fuel level	Add fuel.
	Overload	Reduce load; check load use, and reduce.
	Engine not warmed up	Allow engine to warm up.
<i>For additional information concerning an engine problem, consult the Engine Operation Manual.</i>		
COMPRESSOR		
Compressor overheats This condition will cause a compressor shutdown and compressor fault light to turn on. Before restarting the compressor, determine the cause for overheating.	Low compressor oil level	Check oil level and refill to proper level if necessary (ensure machine is parked on a level surface).
	Obstructed fluid cooler	Clear debris/dirt from cooler core/flush shroud.
	Obstructed cooler fins	Clear/clean if required.
	Insufficient air flow over cooler	Check for obstructions (frame, body, etc.) to cooling air flow.
	Defective temperature switch	Check switch; replace if necessary.
	Compressor oil filter plugged	Replace compressor oil filter. Also consult Section 5, Table 5A for additional periodic oil filter system maintenance.
	Fan not operating	
		Hydraulic oil low; check hydraulic oil reservoir level; fill as necessary.
		Belt slip on hydraulic pump. Refer to the hydraulic pump sub-sections in Section 5.4.3, Re-tensioning and Replacing the Serpentine Drive Belts .
<i>Continued on next page</i>		

6.2 TROUBLESHOOTING GUIDE		Use Section 7, Illustrated Parts List, to visually identify and confirm any part number that may need to be replaced.
Fault/Malfunction	Possible Cause	Corrective Action
COMPRESSOR (CONTINUED)		
Compressor shuts down with air demand present	Compressor temperature switch opening	Check compressor oil level. Replenish if necessary.
	Restricted cooling air intake	Reposition machine.
	Fan not operating	Refer to Corrective Action under “fan not operating”, under ‘compressor overheats’ category above.
	Compressor oil filter plugged	Replace compressor oil filter. Also consult Section 5, Table 5A for additional periodic oil filter system maintenance.
	Clutch faulty	Inspect; replace if necessary.
	Plugged or restricted cooler core	Flush cooler. Consult the Vanair® Service Department for assistance in cleaning/ flushing the cooler core.
	Contaminated cooler fins	Clean cooler fins.
Compressor will not build up pressure	Low compressor oil level	Check oil level and refill to proper level if necessary (ensure machine is parked on a level surface).
	Air demand too high	Check for leaks and take corrective action.
		Check air tools for wear, damage, or malfunctions. Replace or repair.
	Compressor capacity too low to accommodate demand	Substitute larger capacity compressor system.
	Compressor air filter plugged	Check compressor air filter. Replace if necessary.
	Pressure switch out of adjustment	Reset pressure switch. Refer to Section 5.4.2, Adjusting the Pressure Setting . Replace if switch continues to deviate from setting.
	Defective pressure switch	Replace pressure switch.
	Belt(s) slipping	Re-situate and adjust belt tension, or replace belt if necessary. Consult Section 5.4.3, Re-tensioning and Replacing the Serpentine Belts .
Service valve is open	Close service valve.	
<i>Continued on next page</i>		

6.2 TROUBLESHOOTING GUIDE		Use Section 7, Illustrated Parts List, to visually identify and confirm any part number that may need to be replaced.
Fault/Malfunction	Possible Cause	Corrective Action
COMPRESSOR (CONTINUED)		
Compressor will not build up pressure (continued)	Pressure gauge is malfunctioning	Check pressure gauge function/control line routing: adjust, repair or replace as necessary. Check for proper operation with an auxiliary air source. Replace if necessary.
	Inlet solenoid valve fails to open	Repair/replace inlet valve.
	Inlet valve frozen shut	Repair/replace inlet valve.
	Clutch faulty	Inspect; replace if necessary.
	Broken or loose belt	Re-tension or replace belt.
Compressor system over-pressures This condition will cause a compressor shutdown, and a fault light will turn on. Before restarting the compressor, determine the cause of the over-pressure. May also cause the relief valve to open.	Pressure switch setting too high	Reset pressure switch. Refer to Section 5.4.2, Adjusting the Pressure Setting . Replace if switch continues to deviate from setting.
	Pressure switch malfunction	Check for operation/damage: repair or replace.
	Unload solenoid valve defective	Replace solenoid valve.
	Leak in air control line	Check for leaks and take corrective action.
	Restriction in control line	Clean if soiled; if ice is present, clear and remove.
	Damaged/kinked control line	Check line for damage (wear, kinks, etc.). Re-route, re-tie or replace if necessary (refer to Section 7.22, Hose Installation Guide for assistance in running or checking hose lines).
	Inlet valve piston is stuck in down position.	Check for proper operation with an auxiliary air source—replace or rebuild inlet valve.
	Compressor shaft seal is leaking	Replace shaft seal with available kit.
	Plugged coalescer	Replace coalescer.
Control line connections are not properly seated/poor connection quality	Check lines for proper seating/ensure line ends have been cut cleanly and are square. <ul style="list-style-type: none"> • Refer to Section 7.22, Hose Installation Guide for assistance in running or checking hose lines. • DO NOT use wire cutters: use a loom cutting tool or a clean, sharp razor blade. 	
<i>Continued on next page</i>		

6.2 TROUBLESHOOTING GUIDE		Use Section 7, Illustrated Parts List, to visually identify and confirm any part number that may need to be replaced.
Fault/Malfunction	Possible Cause	Corrective Action
COMPRESSOR (CONTINUED)		
No service air output (See also <i>Compressor will not build up pressure</i>)	If equipped, OSHA valve/velocity fuse, not functioning properly	Reset or replace OSHA valve.
	Clogged compressor air filter	Check compressor air filter; replace if necessary
	Solenoid valve sending continuous signal to inlet valve	Rebuild or replace solenoid valve if defective.
	Incorrect compressor speed	Adjust speed. Refer to Section 5.4.2, Adjusting the Pressure Setting .
	Minimum pressure/check valve is malfunctioning	Rebuild or replace check valve.
	Belt not tensioned properly	Check belt tension; replace belt(s) if necessary. Refer to Section 5.4.3 for belt maintenance or replacement procedures.
Compressor stalls	Pressure switch setting too high	Adjust pressure switch setting. Refer to Section 5.4.2, Adjusting the Pressure Setting . Replace if switch continues to deviate from setting.
	Speed is set too low	Check to see if compressor goes to high speed.
System operating pressure below specified minimum	Air demand too high	Check air tools for wear, damage, or malfunctions. Replace or repair.
	Compressor capacity too low to accommodate demand	Substitute larger capacity compressor system.
	System leaks or is damaged	Inspect for leaks. Repair and/or replace damaged parts as necessary.
	Pressure switch set too low/ malfunction	Adjust pressure switch setting. Section 5.4.2, Adjusting the Pressure Setting . Replace if switch continues to deviate from setting.
	Input rpm too low	Adjust to proper setting.
	Contaminated inlet valve	Remove valve and clean piston. Order inlet valve repair kit if necessary.
	Inlet solenoid valve fails to open	Repair/replace inlet valve.
	Inlet valve frozen shut	Repair/replace inlet valve.
<i>Continued on next page</i>		

6.2 TROUBLESHOOTING GUIDE		Use Section 7, Illustrated Parts List, to visually identify and confirm any part number that may need to be replaced.
Fault/Malfunction	Possible Cause	Corrective Action
COMPRESSOR (CONTINUED)		
Excess amount of oil in air discharge	Machine not on level surface	Move machine to level surface.
	Scavenger system not operating	Inspect scavenger line for obstructions or leaks. Replace if necessary.
	Coalescer element plugged or damaged	Replace the coalescer element.
Excessive moisture in the compressed air	Moisture accumulating in air tank	Drain water from air tank.
	Emulsified or contaminated compressor oil	Change oil. Refer to Section 5, Table 5A.
	Compressor oil overfull	Drain excess oil.
HYDRAULIC PUMP		
⚠ IMPORTANT:	<i>Only qualified technicians using proper tools and techniques should attempt any testing or repairs on pressurized systems.</i>	
No hydraulic output	Low hydraulic fluid level	Check and refill (Damage has occurred).
	Hydraulic solenoid valve not opening	Verify electrical function repair as necessary / Replace.
	Hydraulic line obstructed	Check for kinked, crimped, or damaged hoses.
	Hydraulic pump / drive failure	Check belt drive system.
Low hydraulic output	Low hydraulic fluid level	Check and refill.
	Engine speed too low	Check engine speeds.
	Hydraulic line obstructed	Check for kinked, crimped, or damaged hoses.
	Cold oil	Allow time for oil to heat up (Dead head outriggers).
Hydraulic system overheating / fluid smells burnt	Duty cycle too high	Add a hydraulic cooler or reduce duty cycle.
	System pressure set too high	Check and adjust pressure setting.
	Worn or damaged motor	Replace.
Pressure too low	Pressure comp mis-adjusted	Readjust or replace.
	Pressure relief mis-adjusted	Readjust or replace.
	Pump controls damaged	Cycle controls, clean, replace.
Pump Noisy	Cavitation / pump inlet obstruction	Check hydraulic suction line.
<i>Continued on next page</i>		

6.2 TROUBLESHOOTING GUIDE		Use Section 7, Illustrated Parts List, to visually identify and confirm any part number that may need to be replaced.
Fault/Malfunction	Possible Cause	Corrective Action
HYDRAULIC PUMP (CONTINUED)		
Pump Noisy (continued)	Cold oil	Allow time for oil to heat up (Dead head outriggers).
	Low hydraulic fluid level	Check and refill.
	Aeration	Tighten leaky fittings, fill, and bleed air from system
	Worn or damaged pump	Replace Pump
	Pump drive Belt loose/damaged	Tighten or replace pump drive Belt

6.3 EXTREME CONDITION OPERATION

When operating in extreme cold or hot conditions, ranging from 0°F to 110°F (-18°C to 43°C); 0°F to -40°F [-18°C to -40°C] with cold weather kit, at a high altitude, or in the presence of high humidity, additional attention should be given to any indication that could lead to a serious problem. If the ambient temperature varies largely, the environment is dusty, or the engine is operated at a high altitude, the engine performance is directly or indirectly influenced.

Machine review and maintenance check schedules should be more frequent than the normal suggestions given in **Section 5, Table 5A: Maintenance Schedule**.

Become familiar with the alternative operation approaches given in this section before operating the power system package in any type of extreme ambient condition. For additional operation information consult the Engine Operation Manual, or visit the engine manufacturer's web site.

6.3.1 COLD WEATHER OPERATION

NOTE
Refer to the Engine Operation Manual for standard oil recommendations.

Refer to **Table 6.3A**. The PowerFlex™ AH's 25HP engine runs on diesel fuel, which can be more difficult to start in cold weather. When the temperature is very low, extra care must be taken regarding fuel and oil changes in their viscosity, freezing of water contained in the piping, or of water adhering on the filter. Diesel fuel may gel at very cold temperatures.

WATER

Water in the fuel can freeze at temperatures below 32°F (0°C), blocking fuel lines. Keep the fuel tank full to prevent condensation from forming inside the tank and lessen the chances of water getting in the fuel line.

At an extremely cold temperature, the viscosity of hydraulic fluid and lubrication oil may increase and the torque of starter may exceed its permissible value, hindering proper starting.

GELLING

Diesel fuel turns into a gel-like consistency at temperatures around 0°F (-18°C): The diesel forms wax crystals when the temperatures drop below 15°F (-9°C). Then, as it gets colder, these wax crystals turn to gel. This thicker substance cannot pass the fuel filter, so the engine may run intermittently, or may not start at all.

At an extremely cold temperature, the viscosity of hydraulic fluid and lubrication oil

TABLE 6.3A COLD WEATHER OPERATION

Symptom	Cause	Prevention / Corrective Action
<p>Water freezes in the fuel line</p> <p>Lubrication oil viscosity increases</p> <p>Diesel fuel turns to a gel-like consistency at temperatures around 0°F (-18°C)</p>	<p>WATER</p> <p>Water in the fuel can freeze at temperatures below 32°F (0°C), blocking fuel lines.</p> <p>At an extremely cold temperature, the viscosity of lubrication oil may increase and the torque of starter may exceed its permissible value, hindering proper starting.</p> <p>GELLING</p> <p>The diesel forms wax crystals when the temperatures drop below 15°F (-9°C).</p> <p>As it gets colder, these wax crystals turn to gel. This thicker substance cannot pass the fuel filter, so the engine may run intermittently, or may not start at all.</p>	<ul style="list-style-type: none"> • Park the vehicle or equipment indoors when not in use. • Use a block heater or glow plugs. • Maintain the battery; this will make it easier to start a diesel engine in cold weather. • In below zero temperatures a fuel line deicer product may need to be used. • Check the fuel filter regularly to insure that it contains no water. • For additional engine precautions, consult the Engine Operation Manual. • Vanair® recommends installation of the cold weather heater option kit. Consult Vanair for details. • Keep the fuel tank full to prevent condensation from forming inside the tank and lessen the chances of water getting in the fuel line. • The standard recommendation of 15W-40 engine oil is suitable for temperatures down to -4°F (-20°C). If temperatures are consistently below 30°F (-1°C), it is recommended that 5W-30 oil be used. If temperatures are below -25°F (-32°C), a high-performance, fully synthetic oil, such as AMSOIL 5W-30 should be used which is suitable to temperatures of -55°F (-48°C).

may increase, and the torque of starter may exceed its permissible value, hindering proper starting. Additional care should be taken under consideration when operating the package in extreme cold weather environments or ambient temperatures.

COLD WEATHER SAFEGUARDS

- Park the vehicle or equipment indoors when not in use.
- Use a block heater or glow plugs.

- After initial start-up, run engine at idle speed for several minutes prior to use.
- Maintain the vehicle's battery; this will make it easier to start a diesel engine in cold weather.
- In below zero temperatures a fuel line de-icer product may need to be used.
- Check the fuel filter regularly to insure that it contains no water.
- Vanguard™ Premium Synthetic Oil is suitable for use from -40°F to 110°F (-40°C to 43°C).
- Drain the moisture from the tank when it is warm from extended operation.
- For additional engine precautions, consult the Engine Operation Manual.

NOTE

As indicated in the *Section 4.2 (start-up)*, a full interval lapse of ten (10) seconds allows the glow plugs to assist with key ignition start up in cold ambient temperatures.

NOTE

DO NOT use compressor for short periods of time. Compressor must run at operating temperature or moisture will build up in tank.

6.3.2 HIGH TEMPERATURE OPERATION

Refer to **Table 6.3B**. High compartment temperatures can be caused by high ambient temperatures, small engine room, soundproof cases and other reasons. Among these the most important factor is the temperature of the intake and cooling air. Reduce load duty cycle to less than 60% when operating in ambient temperatures above 104 °F (40 °C).

Extra care should be taken to keep the engine and air compressor clean and to not restrict the air flow around the unit. Consult the Engine Operation Manual for fuel, lubrication oil and cooling requirements under extreme temperatures.

When operating the machine in high temperature areas, precautions should be taken to prevent overheating. At the minimum, all coolers, including air passage ways around the coolers, should be free of

debris and dirt. The fan, driven by its own hydraulic motor, is designed to run continuously to assure a constant flow of cooling air.

The operator should be aware that high temperatures can influence engine performance, which can directly effect some machine function capacity outputs.

6.3.3 HIGH DUST CONTENT OPERATION

When the machine is to be used in continuously dusty environments, special care must be taken with the engine's air cleaner and radiator, the compressor air filter and cooler assembly, and the hydraulic fan. The intake air must be cleaned with the air cleaner. Lowering of the radiator cooling capacity due to clogging dust must be prevented. If intake air resistance becomes higher, this will result in reduced output. In order to maintain air-tight seals at the joining sections of the intake system component parts, and thus to prevent foreign matter from entering, it is necessary to ensure the security of the air intake system to prevent the component parts from being damaged. This can be accomplished by performing more frequent monitoring of the air filters, air evacuator valve (on compressor air filter), and radiator coolers and their immediate

TABLE 6.3B HIGH TEMPERATURE OPERATION		
Symptom	Cause	Prevention / Corrective Action
<p>Overheating/high compartment temperatures</p> <p>Diminished engine performance</p>	<p>High ambient temperatures, confined spaces, soundproof cases and other reasons. Among these the most important factor is the temperature of the intake and cooling air.</p>	<ul style="list-style-type: none"> • Extra care should be taken to keep the engine clean and to not restrict the air flow around the unit. • Consult the Engine Operation Manual for fuel, lubrication oil and cooling requirements under extreme temperatures. • At the minimum, all coolers, including air passage ways around the coolers, should be free of debris and dirt. The fan, driven by the engine, is designed to run continuously to assure a constant flow of cooling air. <p>The operator should be aware that high temperatures can influence engine performance, which can directly effect some machine function capacity outputs.</p>

surroundings when operating in areas that contain a high dust content.

If the package is not being used for an extended period of time, an additional precaution, such as covering the machine with a tarp, will help to keep the inside of the machine free of dust particle accumulation.

6.3.4 HIGH ALTITUDE OPERATION

Refer to diagram shown in **Figure 6-2** for altitude and humidity causal effects on diesel engines.

6.3.5 HIGH MOISTURE CONDITION: EMULSIFICATION OF OIL IN ROTARY SCREW COMPRESSOR SYSTEMS

Consult the information in **Table 6.3C** for preventative and/or repair measures. If machine is operating in a high moisture environment, water contamination may persist after following the regular preventative maintenance schedule and standard operating procedures.




Figure 6-2: De-rating Diagram - Altitude and Relative Humidity Effect on Diesel Engines

TABLE 6.3C HIGH MOISTURE CONDITION OPERATION

Symptom	Cause	Prevention / Corrective Action
<p>Emulsification of oil in compressor system:</p> <ul style="list-style-type: none"> • Compressor oil is milky white in color • Compressor oil is broken down and lacks lubricity. • Compressor oil may develop solid chunks or clumps 	<p>Operating the compressor system for short periods of time:</p> <ul style="list-style-type: none"> • Short cycling prevents the temperature of the oil from attaining a high enough temperature capable of vaporizing the moisture droplets. <p>Operating the compressor system unloaded without air flow from the service line for long periods of time:</p> <ul style="list-style-type: none"> • This can keep the oil temperature from getting hot enough to vaporize the moisture droplets, preventing the moisture from being able to escape the system. Additionally, there is no path for the moisture to escape the system. <p>The thermal valve is faulty and activating the cooling fan too soon:</p> <ul style="list-style-type: none"> • This prevents the oil from attaining a high enough temperature capable of vaporizing the moisture droplets. <p>The air filter is saturated with water:</p> <ul style="list-style-type: none"> • This forces moisture to be ingested by the compressor. <p>Any of the above causes will be exacerbated in especially humid environments.</p>	<p>RECOMMENDED CHANGES:</p> <p>If the problem is not corrected by standard operating practices and regular preventative maintenance, consider the following:</p> <ul style="list-style-type: none"> • Raise the average temperature of the compressor oil. • Change the operating procedure to allow for the compressor oil temperature to reach 180 °F before discharging any air. If the compressor isn't discharging any air, it's not ingesting any potentially humid air. It will build pressure upon initial startup, but then it will run closed and allow it to heat up. <p>REPAIR/MAINTENANCE:</p> <p>Refer to Section 5 of the Operation Manual for inspection, cleaning, and repair instructions.</p> <ol style="list-style-type: none"> 1. Once the compressor oil becomes emulsified, it must be replaced along with the oil filter. Depending on the severity, other parts might also need to be replaced. 2. Check that the separator element is in good, working condition. 3. Check that the scavenge line is working properly. <p>If the system is badly contaminated, Vanair® recommends a lube flush that will help clean out any remaining contamination throughout the system. Consult Vanair Service Department for lube flush instructions.</p> <p>Check the moisture drain frequently on the air tank reservoir, to alleviate moisture build-up.</p>